

HQ-DENUCLEAN OX

CLEANING & purifying



WATER TREATMENT  DOSING TECHNIQUE  WATERMETERS  CLEANING

Waterschoot HQ-Line BV | Groenstraat 18/B | 2450 Meerhout | BELGIUM
T.+32 14 308 431 | info@hq-line.be | www.hq-line.be

HQ-DENUCLEAN OX

CLEANING & PURIFYING

DenuClean Ox is a liquid oxidizing cleaning and disinfecting agent for surfaces and drinking water systems in barns and greenhouses during downtime. DenuClean Ox is a uniquely broad-spectrum product effective against organic contaminants, lime scale, iron, and manganese. It provides broad-spectrum cleaning action against organic contamination, lime scale, bacteria, iron, and manganese. For professional use only.

CHARACTERISTICS

Shape : Liquid
pH (1%aq) : ± 3
Odour : Neutral
Safety : ADR, corrosive
Proportion : Miscible with water
in any proportion

INGREDIENTS

Combination of stabilized hydrogen peroxide (540gr /ltr) with phosphoric acid, stabilizers and surfactants.

ALL INGREDIENTS COMPLY WITH EU LEGISLATION
AND ARE BIODEGRADABLE

MODE OF ACTION

DenuClean Ox provides broad-spectrum cleaning action against organic contamination, lime scale, bacteria, iron, and manganese. Biofilm is a major issue affecting productivity in livestock farming. It creates an environment where pathogens can thrive and reduces water flow. It can block drinking nipples, drip lines, and piping systems, and it diminishes the effectiveness of additives in drinking water such as vaccines, medications, and other substances.

ADVANTAGES

- 💧 Biodegradable, no residual products
- 💧 Removes biofilm and limescale
- 💧 Prevents blocked nipples, drip hoses and pressure loss in water systems
- 💧 Prevents the growth of pathogens
- 💧 Contains no heavy metals and is completely biodegradable

USAGE

Surfaces : Clean these first, then use 0.5% solution.

Contact time depends on the application.

Drinking water systems : First clean, rinse and then 4-6 hours circulating with a 1-4% solution.

Rinse with cold and clean water during periods of inactivity.

USE SAFELY, READ THE LABEL AND PRODUCT INFORMATION BEFORE USE

UFI nr: CWG0-S08C-A00Q-6JXF | DENUCLEAN OX V1F24 FLYER

HQ-Line believes the information contained in this data sheet to be true and accurate at the time of publication. However, all instructions, recommendations, and suggestions provided herein are given without any implicit or explicit warranty. Since conditions of use are beyond HQ-Line's control, HQ-Line disclaims all responsibility of any kind for any losses or damages that may result from the use of the data or suggestions provided.